

# Lab - Connect to a Wireless Router

## **Objectives**

- Connect a PC to a wireless router using Ethernet cable
- Configure the PC with an appropriate IPv4 address
- Verify the PC configuration using a Command Prompt

## **Background / Scenario**

For a PC to communicate in the local network and the Internet, it must be connected to a network device.

### **Required Resources**

- 2 PCs (Windows 10) with wired Ethernet NIC on each PC
- 1 Wireless router
- 2 Straight-through Ethernet cables

## **Step 1: Identify Ethernet ports.**

a. On the wireless router, locate the Ethernet (Local Area Network) LAN ports. The Ethernet LAN ports connect your network hosts and devices. The four LAN ports are grouped together in the center of the router as shown in the following figure.



b. On the PC, locate the Ethernet port. The port could be integrated into the motherboard or it could be an adapter. In either case, the port will be an RJ-45 port.


### Step 2: Connect the cable between the PC and the router.

- a. Connect one end of the straight-through Ethernet cable to an Ethernet LAN port on the router.
- b. Connect the other end of the cable to the PC Ethernet port.
- c. Repeat this procedure for the second PC.


#### Step 3: Assign the PCs an IPv4 address and default gateway.

a. Right-click **Start** button > select **Network Connections**.


b. In this example, right-click the Local Area Connection for the wired connection. Select Properties.




c. Double-click the Internet Protocol Version 4 (TCP/IPv4) option to open the TCP/IP properties window.



d. You will enter an IPv4 address configuration consisting of an IPv4 address, a subnet mask, and default gateway address. To enter the address information, click the **Use the following IPv4 address** button.



e. In the IPv4 address field, enter **192.168.10.2**. In the subnet mask field, enter **255.255.255.0**. In the default gateway field, enter **192.168.10.1** as shown in the figure. The DNS server information is not necessary at this time.



f. When finished, click **OK** to return to the Internet Protocol (TCP/IPv4) Properties window. Click **OK** to apply the changes.

After the changes are applied, you will be returned to the Network Connections window.

g. Because the two computers are on the same network, their IPv4 addresses will be similar, their subnet masks will be identical, and their default gateways will be identical. Perform the same procedures on the second PC to assign an IPv4 address, subnet mask, and default gateway using the following information:

IPv4 address: . . . . 192.168.10.3 Subnet mask: . . . . 255.255.255.0 Default gateway: . . . . 192.168.10.1

Why do you think the IPv4 addresses are different, but the subnet masks and default gateways are the same?

### Step 4: Verify the IPv4 address configuration

- a. Right-click Start and select Command Prompt.
- b. At the prompt, type **ipconfig /all** to verify the configured IPv4 address and the default gateway from the previous step for both PCs.

## Step 5: Test connectivity between the two PCs.

 a. From the command prompt on the first PC, test connectivity with the second PC by typing ping 192.168.10.3.

```
Microsoft Windows [Version 10.0.10586]
(c) 2015 Microsoft Corporation. All rights reserved.

C:\Users\Bob>ping 192.168.10.3

Pinging 192.168.10.3 with 32 bytes of data:
Reply from 192.168.10.3: bytes=32 time=1ms TTL=255

Ping statistics for 192.168.10.3:
Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
Minimum = 1ms, Maximum = 1ms, Average = 1ms

C:\Users\Bob>
```

b. The pings should be successful. If the pings are not successful, perform the appropriate troubleshooting steps, such as checking the cabling and checking your IPv4 address, subnet mask, and default gateway assignments.